

Is Your Product Registered?

Contact your Dealer to verify.

Warranties are based on Registrations and reduced to 1 year without
Registration.

PARTS LIST

BL32-1

CONTENTS


1. MAIN BODY	1 ~ 2
2. ENGINE (Cylinder, Crankcase)	3 ~ 6
3. ENGINE (Carburetor, Fuel Tank)	7 ~ 10
4. ACCESSORIES	11 ~ 12

2012. 12.




P/N 523531

1. BL32-1
MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	395833	BL32-1(MUS)	1	
1-2	859168	Engine	1	CE300/74
1-3	281535	Fan Case	1	
1-4	281586	Stopper (A)	1	
1-5	281867	Stopper (B)	1	
1-6	282862	Washer	1	
1-7	269423	Nut	1	
1-8	126993	Nut	1	M5
1-9	261246	Cap Screw	1	M5x25
1-10	281880	Grip (B)	1	
1-11	281865	Stand	2	
1-12	281862	Cable Comp.	1	
1-13	281585	Lever	1	
1-14	282170	Switch Ass'y	1	Incl.15-18
1-15	281863	Switch	1	
1-16	282028	Label	1	
1-17	282171	Knob	1	
1-18	282172	Screw	1	
1-19	281536	Fan Cover	1	
1-20	281869	Plate	1	
1-21	280008	Nut	1	M4
1-22	282060	Tapping Screw	4	4x10
1-23	281563	Cover	1	
1-24	281870	Spring	1	
1-25	281878	Rod	1	
1-26	263743	Washer	1	5.7x15.8xt2
1-27	282149	Knob	1	
1-28	281989	Tapping Screw	7	5x20
1-29	281873	Washer	2	8.5x26xt2.9
1-30	281874	Fan	1	
1-31	283041	Nut	1	M8
1-32	282549	Label	1	
1-33	289968	Label	1	BL32-1
1-34	288307	Label	1	BL32
1-35	261250	Cap Screw	4	M5x20
1-36	281538	Handle	1	
1-37	281879	Grip (A)	1	
1-38	281989	Tapping Screw	5	5x20

2. BL32-1
ENGINE (Cylinder, Crankcase)




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	859168	Engine	1	CE300/74
2-2	286791	Cylinder	1	
2-3	286846	Gasket	1	
2-4	261250	Cap Screw	4	M5x20
2-5	282579	Insulator	1	
2-6	281590	Air Duct	1	
2-7	261171	Gasket	2	
2-8	265924	Cap Screw	2	M5x25
2-9	282585	Muffler Ass'y	1	Incl.10-13
2-10	282586	Muffler Comp.	1	
2-11	281860	Tail	1	
2-12	267056	Spark Arrester	1	
2-13	265107	Cap Screw	2	M4x10
2-14	268461	Holder	1	
2-15	281589	Gasket	1	
2-16	266713	Cap Screw	2	M5x60
2-17	261607	Cap Screw	1	M5x16
2-18	281537	Top Cover	1	
2-19	281989	Tapping Screw	2	5x20
2-20	265724	Cap Screw	2	M4x25
2-21	286851	Crankcase	1	
2-22	280488	Bearing	2	PPL 6001
2-23	261492	Oil Seal	1	ISCD12287
2-24	261386	Oil Seal	1	ISCD12227
2-25	055185	Snap Ring	1	#28
2-26	261612	Cap Screw	3	M5x30
2-27	281442	Screen	1	
2-28	268782	Piston	1	
2-29	265067	Piston Ring	2	(2)Required
2-30	265068	Piston Pin	1	
2-31	265225	Bearing,Needle	1	
2-32	261393	Clip,Piston Pin	2	
2-33	265141	Crankshaft/Conn.Rod Ass'y	1	
2-34	287004	Magneto Ass'y	1	Incl.35,36
2-35	286889	Rotor/Fan	1	
2-36	282010	Ignition Coil Ass'y	1	
2-37	261076	Woodruff Key	1	3x10
2-38	281872	Shaft	1	
2-39	280381	Spacer	2	
2-40	261256	Cap Screw	2	M4x25
2-41	285982	Spark Plug	1	NGK BPM8Y
2-42	281864	Lead	1	
2-43	282087	Lead	1	
2-44	281172	Grommet	1	
2-45	283039	Recoil Starter Ass'y	1	Incl.46-55

2. BL32-1
ENGINE (Cylinder, Crankcase)




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-46	283502	Starter Ass'y	1	Incl.47-54
2-47	283504	Reel	1	
2-48	283505	Cam Plate	1	
2-49	283506	Spring	1	
2-50	283507	Spiral Spring	1	
2-51	267213	Screw	1	
2-52	283509	Starter Rope	1	
2-53	283510	Starter Grip	1	
2-54	283511	Rope Stopper	1	
2-55	280934	Starter Pawl Ass'y	1	
2-56	265724	Cap Screw	2	M4x25
2-57	288303	Label	1	BL32

3. BL32-1
ENGINE (Carburetor, Fuel Tank)




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	282528	Carburetor Ass'y	1	Incl.2-18 New gasket required
3-2	264155	Pump Body	1	
3-3	262991	Purge Body	1	
3-4	262992	Cover Plate	1	
3-5	261874	Primer Bulb	1	
3-6	283905	Diaphragm, Meterring	1	
3-7	262993	Gasket	1	
3-8	262994	Diaphragm,Fuel Pump	1	
3-9	282576	Gasket	1	
3-10	261876	E-Ring	1	
3-11	261658	Swivel	1	
3-12	261875	Screw	2	
3-13	264677	Bracket	1	
3-14	261878	Nut	1	
3-15	261877	Adapter	1	
3-16	261657	Packing	1	
3-17	262996	Screw	4	
3-18	264678	Washer	1	
3-19	282578	Gasket	1	
3-20	268055	Air Filter Case Ass'y	1	Incl.21-24
3-21	268056	Air Filter Case	1	
3-22	268057	Valve	1	
3-23	268412	Sleeve	1	5.5x7.1x6.6L
3-24	268157	Sleeve	1	5.5x7.1x6L
3-25	263345	Packing	1	7.2x11xt1.3
3-26	263942	Washer	1	7.2x12xt0.15
3-27	263815	Stay	1	
3-28	264016	Cap Screw	2	M5x60
3-29	265026	Screen	1	
3-30	281861	Element	1	
3-31	268058	Air Filter Cover Ass'y	1	Incl.32-34
3-32	268059	Air Filter Cover	1	
3-33	281438	Knob	1	
3-34	261734	Snap Ring	1	#5
3-35	289038	Fuel Tank Ass'y	1	Incl.36-48
3-36	283891	Fuel Tank	1	
3-37	289043	Fuel Tank Cap Ass'y	1	Incl.38
3-38	287058	Gasket	1	
3-39	289035	Fuel Pipe Pick-up Ass'y	1	Incl.40-48
3-40	289036	Fuel Pipe Ass'y	1	Incl.41-43
3-41	268065	Grommet	1	
3-42	261590	Breather	1	
3-43	261117	Clip	1	
3-44	289028	Pipe A	1	3x5x53L
3-45	288921	Joint	1	

3. BL32-1
ENGINE (Carburetor, Fuel Tank)



Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-46	289033	Pipe	1	3x5x100L
3-47	264653	Filter Ass'y	1	
3-48	261117	Clip	3	
3-49	261117	Clip	1	
3-50	268940	Screw	2	M5x18
3-51	281715	Cap Screw	1	M5x20
3-52	261352	Label	1	Choke
3-53	285188	Label	1	

4. BL32-1
ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	281875	Pipe (A)	1	
4-2	281876	Pipe (B)	1	
4-3	282738	Tool Set	1	Incl.4,5
4-4	219431	Wrench	1	3mm
4-5	210418	Box Spanner	1	13x19x(+)
4-6	289743	Instruction Manual	1	BL32-1
4-7	289744	Intake Hood Ass'y	1	Incl.8,9
4-8	127279	Intake Hood	1	
4-9	289745	Label	1	MARUYAMA