


MARUYAMA

ILLUSTRATED PARTS LIST

BL5500SP

BL5500HA

BACKPACK BLOWER




BL5500SP/BL5500HA
BACKPACK BLOWER
PART 845406-REV06/03



Maruyama. *E x t r a o r d i n a r y .*

2 ILLUSTRATED PARTS LIST
BL5500SP & BL5500HA


MAIN BODY



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	634345	Shroud	1	
2	121753	Inlet Pipe	1	
3	121755	Band	1	
4	119684	Band	1	
5	092543	Bolt	4	M6x45
6	108634	Earth Cord	1	
7	103550	Clamp	1	
8	082697	Tapping Screw	1	M5x10
9	120512	Fan Case (E)	1	
10	119387	Fan Case (S)	1	
11	118530	Tapping Screw	11	M5x25
12	119160	Collar	1	
13	119161	Rubber Band	1	
14	120615	Buffer	2	
15	118724	Fan	1	
16	118248	Plate	1	
17	119558	Bolt	3	M6x40-7T
18	012502	Spring Washer	3	M6
19	634055	Air Cleaner Ass'y	1	Incl. 20-23
20	122951	Element	1	
21	114463	Knob	2	
22	014187	O-Ring	2	
23	120625	Knapsack Band	2	
24	083445	Screw	2	M6x16
25	550132	Nut	2	M6
26	120614	Band	1	
27	109704	Nut	4	M6
28	119177	Cushion Pad	1	
29	840543	Fastener	4	
30	119388	Fuel Tank Ass'y	1	Incl. 32-34
31	120154	Fuel Tank	1	
32	119390	Cap Ass'y	1	
33	119391	Filter Ass'y	1	
34	081414	Screw	2	M5x14
35	015479	Washer	2	
36	120536	Packing	1	
37	119174	Knapsack Frame	1	
38	026223	Buffer	2	
39	120616	Collar	2	

4 ILLUSTRATED PARTS LIST
BL5500SP & BL5500HA


MAIN BODY



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
40	120617	Packing	2	
41	120077	Tapping Screw	4	M6x14
42	121757	Label	1	BL5500SP
42	121778	Label	1	BL5500HA
43	121132	Label	1	
44	119613	Label	1	Choke


6 ILLUSTRATED PARTS LIST
BL5500SP

THROTTLE



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	121756	Throttle Ass'y	1	Incl. 2-9
2	122046	Throttle	1	
3	118811	Grip	1	
4	118813	Band	1	
5	118814	Band	1	
6	120319	Tapping Screw	2	M5x18
7	117488	Knob Bolt	1	M6x30
8	121634	Throttle Cable Ass'y	1	
9	121427	Tube	1	
10	119173	Clamp	1	


THROTTLE



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	117622	Throttle Lever Ass'y	1	Incl. 2-17
2	107126	Arm	1	
3	107127	Lever	1	
4	107221	Spring	1	
5	106498	Ball	1	
6	107129	Stay	1	
7	019001	Tapping Screw	2	M4x10
8	081457	Screw	1	M6x25
9	012502	Spring Washer	1	M6
10	012488	Washer	1	M6
11	107136	Collar	1	
12	081031	Nut	1	M6
13	115605	Flange	1	
14	115612	Knob Bolt	1	M8x35
15	107581	Nylon Nut	1	M8
16	065842	Cotter Pin	1	
17	117623	Switch	1	
18	081456	Screw	4	M6x20
19	013754	Washer	8	M6
20	112509	Nut	4	M6
21	117603	Plate	1	
22	121776	Throttle Cable Ass'y	1	

10 ILLUSTRATED PARTS LIST
BL5500SP & BL5500HA


ENGINE



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	634340	Cylinder	1	
2	570248	Gasket	1	
3	634341	Gasket	1	
4	634342	Crankcase	1	
5	634343	Crankcase	1	
6	597283	Bearing	2	#6202C3
7	071320	Oil Seal	2	
8	597284	Bolt	4	
9	944619	Screw	1	
10	599880	Screw	4	
11	943349	Dowel Pin	2	
12	943893	Gasket	1	
13	570244	Piston	1	
14	944769	Piston Pin	1	
15	943304	Piston Ring Set	1	
16	570245	Crankshaft Ass'y	1	Incl. 17
17	597289	Needle Bearing	1	
18	597285	Shim	AR	t=0.10
18	597286	Shim	AR	t=0.20
18	597287	Shim	AR	t=0.40
18	597288	Shim	AR	t=0.60
19	943307	Snap Ring	2	
20	630053	Insulator	2	
21	634344	Shroud	1	
22	634345	Shroud	1	
23	573307	Bolt	2	
24	580184	Screw	1	
25	621123	Washer	2	
26	575415	Washer	2	
27	570252	Cover	1	
28	634346	Flywheel	1	
29	591532	Spark Plug Cap	1	
30	591533	Terminal	1	
31	634347	Ignition Coil Ass'y	1	
32	597263	Lead Wire	1	
33	943924	Washer	1	
34	998409	Key	1	
35	998411	Tube	1	
36	627409	Spark Plug	1	BPMR7A
37	597293	Grommet	1	
38	634348	Grommet	1	
39	943457	Bolt	2	


12 ILLUSTRATED PARTS LIST
BL5500SP & BL5500HA

ENGINE




REF #	PART #	DESCRIPTION	Q'TY.	NOTES
40	998410	Nut	1	
41	998413	Recoil Starter	1	Incl. 42-51
42	998438	Rope Guide	1	
43	944502	Plate	1	
44	998439	Recoil Starter Case	1	
45	998440	Recoil Starter Case	1	
46	998437	Grip	1	
47	998436	Rope	1	
48	998434	Reel	1	
49	998435	Recoil Spring	1	
50	944801	Screw	1	
51	998433	Washer	1	
52	624845	Screw	4	M4x16
53	998414	Starting Pulley	1	Incl. 54-56
54	944226	Snap Ring	1	
55	579573	Return Spring	1	
56	572938	Pawl	1	
57	998417	Nut	1	
58	071344	Washer	2	

CARBURETOR




REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	634352	Gasket	1	
2	634355	Plate	1	
3	634358	Bolt	2	
4	634351	Gasket	1	
5	634349	Gasket	1	
6	634354	Reed Valve Ass'y	1	
7	579565	Screw	3	
8	634353	Gasket	1	
9	634356	Carburetor Ass'y	1	Incl. 10-33
10	626822	Body Ass'y	1	Incl. 11-16
11	624430	Filter	1	
12	624434	Spring	1	
13	624433	Pin	1	
14	624429	Lever	1	
15	624432	Screw	1	
16	624431	Float Valve	1	
17	262993	Gasket	1	
18	634357	Diaphragm	1	
19	598413	Body	1	
20	577191	Priming Pump	1	
21	598409	Primer Pump Cover	1	
22	598417	Screw	4	
23	577179	Screw	2	
24	624525	Bracket	1	
25	598418	Screw	1	
26	624530	Nut	1	
27	577182	O-Ring	1	
28	628092	Main Jet	1	#52
29	598415	Arm	1	
30	624532	Washer	1	
31	577175	Snap Ring	1	
32	634350	Gasket	1	
33	577185	Diaphragm	1	
34	584743	Muffler Gasket	2	
35	634360	Gasket	1	
36	634361	Baffle	1	
37	634362	Spark Arrester	1	
38	634363	Muffler Comp.	1	
39	634364	Muffler Cover	1	

CARBURETOR



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
40	634365	Muffler Cover	1	
41	634366	Screw	4	
42	634367	Screw	2	
43	634368	Bolt	2	
44	944981	Bolt	2	
45	943276	Screw	1	
46	634359	Air Filter Case Ass'y	1	Incl. 47
47	628550	Screw	1	
48	625872	Fuel Filter	1	
49	630564	Valve	1	
50	625871	Cap Ass'y	1	
51	597949	Fuel Tank Grommet	1	
52	597948	Fuel Filter Clamp	2	
53	634369	Clamp	1	
54	625873	Tube	1	
55	625874	Tube	1	
56	634370	Tube	1	
57	634371	Tube	1	
58	598438	Label	1	
59	597314	Label	1	
60	634372	Label	1	

ACCESSORIES



REF #	PART #	DESCRIPTION	Q'TY.	NOTES
1	119186	Flexible Pipe	1	
2	121238	Pipe Ass'y	1	Incl. 3-5
3	121242	Swivel Pipe	1	
4	121243	Straight Pipe	2	
5	121244	Bent Pipe	1	
6	119525	Hose Band	1	
7	081415	Screw	1	M5x16
8	119523	Hose Band	1	
9	081417	Screw	1	M5x25
10	210418	Box Spanner	1	13x19x(+)
11	216007	Warranty Card	1	
12	121758	Instruction Manual	1	



Maruyama U.S., Inc.
3570 Shelby Lane
Denton, TX 76207
940-383-7400 voice
940-383-7466 fax

www.maruyama-us.com