

PARTS LIST

MS076D-TL

CONTENTS


1. MAIN BODY	1
2. CHEMICAL TANK	3
3. POWER SPRAYER	5
4. REDUCTION GEAR.....	9
5. ENGINE	11
6. CARBURETOR, FUEL TANK	15
7. ACCESSORIES	17

2020. 08.




P/N 525072

MS076D-TL
1. MAIN BODY




Ref. No.	Part No.	Part Name	Q'ty	Remarks
1-1	366563	MS076D-TL	1	
1-2	272214	Throttle Cable	1	
1-3	109246	Buffer	2	
1-4	127228	Nut	3	M6
1-5	563141	Base	1	
1-6	131025	Cushion Pad	1	
1-7	100749	Fastener	6	#7
1-8	118002	Stay (R)	1	
1-9	118004	Stay (L)	1	
1-10	123952	Cap Screw	2	M6x14
1-11	127233	Bolt	2	M6x16
1-12	127238	Screw	2	M6x13
1-13	566143	Stay	1	
1-14	081415	Screw	2	M5x16
1-15	127226	Nut	2	M5
1-16	115148	Throttle Lever	1	
1-17	127226	Nut	1	M5
1-18	089747	Bolt	1	M6x12
1-19	126568	Spring Washer	1	M6
1-20	126572	Washer	2	M6
1-21	089750	Nut	1	M6
1-22	114895	Stop Button	1	
1-23	114896	Ground Wire	1	
1-24	114901	Vinyl Hose	1	8x9x220L
1-25	685048	Band	1	CV-150B
1-26	566152	Knapsack Band Ass'y	1	
1-27	127221	Screw	2	M6x16
1-28	127224	Washer	2	6x23xt1.6
1-29	127237	Nut	2	M6
1-30	114917	Buffer	1	

MS076D-TL
2. CHEMICAL TANK




Ref. No.	Part No.	Part Name	Q'ty	Remarks
2-1	566117	Chemical Tank	1	
2-2	118147	Cap	1	
2-3	029299	Packing	1	36xt3.0
2-4	566493	Strainer	1	
2-5	118145	Cap, Chemical Tank	1	Incl.6
2-6	022362	Packing	1	150x170xt10
2-7	566886	Label	1	MS076D
2-8	566106	Label	1	Caution
2-9	563054	Label	1	

MS076D-TL
3. POWER SPRAYER




Ref. No.	Part No.	Part Name	Q'ty	Remarks
3-1	275507	Pump Ass'y	1	Incl.2~52,4-1~4-15
3-2	121831	Crankcase	1	
3-3	102683	Oil Seal	2	G16244
3-4	106190	Collar	2	
3-5	121179	Connecting Rod	1	
3-6	118055	Sleeve	2	15x28.5
3-7	102358	Seal Retainer	2	
3-8	112252	Packing	2	
3-9	013977	O-Ring	2	S26
3-10	043426	Suction Valve Seat	2	5x17xt2.8
3-11	100441	Piston Packing	2	20.5
3-12	023357	Suction Valve Collar	2	5x8x10L
3-13	022023	Suction Valve Stopper	2	5x16xt3
3-14	118357	Bolt	2	M5x45x22
3-15	015848	Spring Washer	2	M5
3-16	021549	O-Ring	2	P5
3-17	100554	Spacer Pipe	2	6x12x10
3-18	014175	O-Ring	4	P9
3-19	103128	Cylinder Head (A)	1	
3-20	102634	Cylinder Head (B)	1	
3-21	013983	O-Ring	2	S31.5
3-22	103130	Cylinder Pipe	2	20x26x18L
3-23	023172	O-Ring	2	P22
3-24	118018	Valve Seat	2	
3-25	103575	O-Ring	2	23x1.5
3-26	043723	Discharge Valve	2	16x1.5
3-27	566164	Discharge Valve Spring	2	
3-28	103746	Valve Seat	1	
3-29	011343	O-Ring	1	P10A
3-30	011346	O-Ring	1	P14
3-31	103132	Spring Case	1	
3-32	121618	Spring Retainer	1	
3-33	011682	O-Ring	1	P10
3-34	121619	Discharge Valve	1	
3-35	566163	Compression Coil Spring	1	
3-36	107198	Handle	1	
3-37	127225	Collar	1	8x10x5.3
3-38	127217	Washer	5	8.5x14xT0.5
3-39	126521	Nut	1	M8
3-40	127216	Washer	1	M8
3-41	121956	Screw	8	M5x32
3-42	816036	Screw	4	M5x60
3-43	102661	Elbow	1	
3-44	108460	Plug	1	R3/8
3-45	118358	Hose Ass'y	1	Incl.46,47

MS076D-TL
3. POWER SPRAYER




MS076D-TL
4. REDUCTION GEAR



Ref. No.	Part No.	Part Name	Q'ty	Remarks
4-1	121621	Reduction Gear Ass'y	1	Incl.2-12
4-2	103137	Clutch Case	1	
4-3	102680	Bearing	2	#6000ZZ
4-4	112184	Bearing	1	#6000DDU
4-5	103138	Gear Case	1	
4-6	118200	Pinion Gear	1	
4-7	103144	Bearing	1	#6004ZZ
4-8	121622	Crankshaft	1	
4-9	127367	Clutch Drum	1	
4-10	125824	Bolt	2	M6x16
4-11	127219	Screw	2	M6x20
4-12	127227	Spack	2	
4-13	118006	Bearing Case	1	
4-14	102680	Bearing	1	#6000ZZ
4-15	127231	Bolt	4	M6x55
4-16	092548	Bolt	4	M5x15


MS076D-TL
5. ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-1	875517	Engine	1	EE263PTH/03
5-2	273153	Cylinder	1	
5-3	282330	Gasket	1	
5-4	261250	Cap Screw	4	M5x20
5-5	263772	Insulator	1	New gasket required
5-6	267049	Gasket	1	
5-7	269826	Screw	2	M5x25
5-8	278560	Muffler Comp	1	
5-9	266264	Cap Screw	2	M5x50
5-10	282252	Gasket	1	
5-11	246083	Under Cover	1	
5-12	269827	Screw	1	M5x16
5-13	278908	Top Cover	1	
5-14	265410	Adapter	1	
5-15	261878	Nut	1	M6
5-16	280144	Tapping Screw	1	
5-17	563680	Crankcase	1	
5-18	280488	Bearing	2	PPL 6001
5-19	563633	Oil Seal	1	
5-20	563632	Oil Seal	1	
5-21	563635	Snap Ring	1	H28
5-22	261612	Cap Screw	3	M5x30
5-23	273155	Piston	1	
5-24	261496	Piston Ring	2	(2)Required
5-25	261497	Piston Pin	1	
5-26	261037	Bearing,Needle	1	KBK8x11x11.8x1
5-27	261576	Clip,Piston	2	
5-28	277939	Crankshaft/Conn.Rod Ass'y	1	
5-29	264887	Clutch Ass'y	1	Incl.30,31
5-30	264888	Clutch Shoe	2	(2)required
5-31	264889	Spring,Clutch	1	
5-32	264505	Bolt	2	
5-33	261777	Wave Washer	2	
5-34	261189	Washer	2	6x16.5x1.2
5-35	283386	Fan Cover	1	
5-36	269831	Screw	4	M5x20
5-37	563372	Magneto Ass'y	1	Incl.38-42
5-38	261356	Rotor/Fan	1	
5-39	282693	Ignition Coil Ass'y	1	Incl.40-42
5-40	282694	Spark Plug Wire Ass'y	1	Incl.41,42
5-41	261074	Plug Boot	1	
5-42	261075	Connector	1	
5-43	261076	Woodruff Key	1	3x10
5-44	261417	Nut,Rotor	1	M8
5-45	280381	Spacer	2	

MS076D-TL


5. ENGINE



Ref. No.	Part No.	Part Name	Q'ty	Remarks
5-46	261256	Cap Screw	2	M4x25
5-47	285982	Spark Plug	1	NGK BPM8Y
5-48	267492	Lead	1	130L
5-49	282880	Wire, Lead	1	
5-50	563258	Recoil Starter Ass'y	1	Incl.51-59
5-51	288685	Starter Ass'y	1	Incl.52-58
5-52	288967	Reel	1	
5-53	288968	Spiral Spring	1	
5-54	262922	Screw	1	
5-55	288969	Starter Rope Ass'y	1	Incl.56-58
5-56	288970	Starter Rope	1	
5-57	261725	Starter Grip	1	
5-58	283511	Rope Stopper	1	
5-59	288971	Starter Pawl Ass'y	1	
5-60	269833	Screw	1	M4x16
5-61	280489	Screw	2	M4x20
5-62	566882	Label	1	



MS076D-TL

6. CARBURETOR, FUEL TANK



Ref. No.	Part No.	Part Name	Q'ty	Remarks	
6-1	275045	Carburetor Ass'y	1	Incl.2-15 New gasket required	
6-2	263739	Pump Body	1		
6-3	262991	Purge Body	1		
6-4	262992	Cover Plate	1		
6-5	261874	Primer Bulb	1		
6-6	283905	Diaphragm, Meterring	1		
6-7	262993	Gasket	1		
6-8	262994	Diaphragm,Fuel Pump	1		
6-9	282576	Gasket	1		
6-10	267358	Main Jet	1		
6-11	261871	O-Ring	1		
6-12	261876	E-Ring	1		
6-13	261658	Swivel	1		
6-14	264682	Screw	2		
6-15	262996	Screw	4		
6-16	261864	Gasket	1	Incl.18-24	
6-17	284823	Case Ass'y	1		
6-18	269050	Case Body	1		
6-19	284802	Valve	1		
6-20	284803	Lever	1		
6-21	284816	Washer	1	6.4x11x0.15	
6-22	269032	Screw	1	M5	
6-23	126993	Nut	1		
6-24	269051	Sleeve	2		
6-25	269030	Element	1	M5x55	
6-26	281777	Screw	2		
6-27	269580	Cleaner Cover	1		
6-28	269031	Screw	1		M5x12
6-29	563400	Fuel Tank Ass'y	1		Incl.30-40
6-30	563101	Fuel Tank	1	Incl.32	
6-31	275306	Fuel Tank Cap Ass'y	1		
6-32	274875	Gasket	1		
6-33	563262	Breather Ass'y	1		
6-34	563232	Fuel Pipe Pick-up Ass'y	1		Incl.35-40
6-35	563233	Fuel Pipe Ass'y	1	Incl.36-38	
6-36	288192	Grommet	1	160L 3x6x85	
6-37	261690	Fuel Pipe	1		
6-38	288194	Return Pipe	1		
6-39	277887	Filter Ass'y	1		
6-40	563014	Clip	1		
6-41	563014	Clip	1	5.5x12x1.6	
6-42	563119	Extension	1		
6-43	563142	Extension	2		
6-44	283688	Washer	3		

MS076D-TL
7. ACCESSORIES



Ref. No.	Part No.	Part Name	Q'ty	Remarks
7-1	118270	Hose Ass'y	1	7.5x1200L
7-2	641261	Grip	1	
7-3	105891	Ball Cock	1	G1/4xG1/4
7-4	124040	Nozzle Pipe Ass'y	1	Incl.5
7-5	112850	Packing	1	11.5x15.5xt1.5
7-6	814267	Wide Nozzle Ass'y	1	Incl.7-12
7-7	103170	Nozzle Body	1	H-606
7-8	106359	Packing	2	H-702
7-9	120738	Strainer	2	
7-10	120739	Packing	2	
7-11	412891	Disk Plate	2	NN-C-35S
7-12	103173	Cap	2	
7-13	210418	Box Spanner	1	13x19x(+)
7-14	219431	Wrench	1	3mm
7-15	219432	Wrench	1	4mm
7-16	022540	Fuel Blending Bottle	1	
7-17	563055	Wide Nozzle Kit	1	Incl.18-30
7-18	124040	Nozzle Pipe Ass'y	1	Incl.19
7-19	112850	Packing	1	11.5x15.5xt1.5
7-20	105891	Ball Cock	1	G1/4xG1/4
7-21	118270	Hose Ass'y	1	7.5x1200L
7-22	641261	Grip	1	
7-23	563124	Fitting	1	PF1/4
7-24	814267	Wide Nozzle Ass'y	1	Incl.25-30
7-25	103170	Nozzle Body	1	H-606
7-26	106359	Packing	2	H-702
7-27	120738	Strainer	2	
7-28	120739	Packing	2	
7-29	412891	Disk Plate	2	NN-C-35S
7-30	103173	Cap	2	
7-31	566887	Instruction Manual	1	